



ANTI-WRINKLE EFFECT

Title	Instrumental assessment of the anti-wrinkle efficacy.
Objective	To assess the anti-wrinkle efficacy of a product after repeated application under normal conditions of use. <i>Optional: To assess subjectively its cosmetic qualities and efficacy.</i>
Schedule	Duration of the study: 28 days minimum. Beginning: 2 weeks upon receipt of the samples. Report: 3 weeks after the end of the study.
Methodology	Analysis of Silflo® replicas of the wrinkles with the Quantirides® software or Visioline® VL 650 software.
Procedure	<ul style="list-style-type: none">• Basal replica of the crow's foot wrinkles.• Use of the product at home by the subjects following the instructions for use.• Post treatment replicas of the same crow's foot wrinkles.• Analysis of the parameters of the wrinkles.• Statistical comparison of the results obtained before and after treatment. <i>Optional:</i> <ul style="list-style-type: none">- <i>Cosmetic qualities and efficacy questionnaire</i>- <i>Professional pictures</i>- <i>Intermediate controls</i>